

VTI Wired Installation Instructions



1. Disconnect the negative connection on vehicle's battery before beginning installation.

2. Identify Power Sources:

■ The **Red Wire** is for Power.

■ The **White Wire** is for the Ignition.

■ The **Black Wire** is the Ground Wire.

⚠ *If you do not wire the white wire to ignition, it must be wired with the red wire to power.*

3. For devices that have an external antenna it should be placed where there is minimal metal above it.

⚠ *Do Not Power on the device until the antenna wires are fully connected.*

4. Once the wires are securely and safely connected, you may connect the power cable to the device. Then, connect the negative cable back to your vehicle's battery.

5. Once power is connected, you should see 2 LEDs on the front of the device light up (this may take several minutes). After you have 2 blinking lights, you will need to drive your vehicle for several minutes to get the vehicle to locate.

Tools Needed:

Voltage Meter, Standard and Phillips screwdrivers, Standard or Metric Socket Set (depending on vehicle's manufacturer), Screws or Zip/Cable Ties



For more detailed installation information, including pictures, go to: www.trackwhatmatters.com/install



View your account at: app.trackwhatmatters.com